

# Crystal Engineering Through Particle Size and Shape Measurement, Kinetic Parameter Estimation, Modeling and Control

James B. Rawlings

Department of Chemical and Biological Engineering  
University of Wisconsin–Madison

Department of Chemical Engineering  
University of South Carolina  
10 April 2006

## Outline

- 1 Crystal engineering overview
  - A brief history
  - A systems engineering perspective
- 2 Modeling of populations
- 3 A stochastic alternative
  - Stochastic kinetics
  - Stochastic population balance
- 4 Experimental applications
  - Control of particle size and shape
  - Model-based image analysis
- 5 Looking to the future: multiscale modeling

## A brief history...

“Crystal Size Distribution Dynamics, Stability and Control (A Review Paper),” Randolph, 1980.

*Technologies do not exist for the on-line instrumental control of CSD.*

*The literature is rife with theoretical studies of CSD stabilization and/or control, but typically the suggested control variable cannot presently be measured and in no case were any of the control algorithms experimentally investigated.*

*The current industrial practice of CSD in industrial crystallizers can be summed up in three words: Hold Everything Constant.*

## A brief history ... 10 years later

“Model Identification and Control of Solution Crystallization Processes: A Review,” Rawlings, Miller, Witkowski, 1993.

*Considerable research effort has been devoted to CSD control, and we are now seeing the advances in measurement and computing technologies necessary for successful industrial implementation.*

*It is reasonable to expect closed-loop CSD control to become part of accepted industrial practice in the near future.*

Technique	Description	Reference
Video Microscopy and Image Analysis	<ul style="list-style-type: none"> <li>● On-line images captured and digitized</li> <li>● Limited to dilute slurries</li> <li>● Shape information present</li> </ul>	Patience and Rawlings (2001) Plummer and Kausch (1995) Bharati and MacGregor (1998)
Lasentec particle and vision measurement (PVM)	<ul style="list-style-type: none"> <li>● In-situ probe coupled with strobing</li> <li>● Numerous images are captured</li> <li>● Dense slurries possible</li> <li>● Randomly oriented particles</li> </ul>	Braatz and Hasebe (2001) lasentec.com
Forward laser light scattering	<ul style="list-style-type: none"> <li>● Energy pattern of scattered light</li> <li>● Ill-conditioned inversion of scattering pattern to CSD</li> </ul>	Heffels et al. (1994,1995) Rawlings et al. (1993) www.malvern.co.uk
Transmittance	<ul style="list-style-type: none"> <li>● In-situ probe</li> <li>● Second moment of CSD</li> <li>● Limited to single scattering</li> </ul>	van de Hulst (1981) Matthews and Rawlings (1998) Patience et al. (2001)
Backward laser light scattering Lasentec focused beam reflectance measurement (FBRM)	<ul style="list-style-type: none"> <li>● In-situ probe</li> <li>● Chord length of CSD</li> <li>● Dense slurries possible</li> </ul>	Monnier et al.(1997) lasentec.com
Electro-zone Sensing (Coulter counter)	<ul style="list-style-type: none"> <li>● Electronically counts particles</li> <li>● Requires a conducting solution</li> <li>● Third moment of CSD</li> </ul>	Allen (1997) Rovang and Randolph (1980)

## A brief history . . . projecting 10 years in the future

“Tailoring Size, Shape and Composition of the Solid Phase,”  
some future researcher, 2010.

*A large investment in process technologies required to achieve reliable manufacturing processes for new products in high value-added industries, such as pharmaceuticals, took place in the 1990s. This investment resulted in a revolution in methods for measuring, monitoring, modeling and controlling the creation of the solid phase from solution. All aspects of this formation are now tailored to meet product quality specifications including the size and shape of particles, as well as the multicomponent composition in the solid mixture. It is not clear why the earlier researchers were such pessimists. . .*

- First we need a model...
  - mathematical abstractions of real processes
  - predict behavior over some operating range of interest
- Systems theory can...
  - provide general tools for extracting information from complex models and experimental data
  - examples
    - steady-state analysis
    - parameter estimation
    - optimization
    - on-line estimation and control

## Modeling of Populations

Dynamics of populations are determined by applying the equation of continuity.

- Conservation Equation

$$\frac{d}{dt} \int_V f(z, t) d\tau = \int_V (B - D) d\tau$$
$$z = \begin{bmatrix} x \\ y \end{bmatrix} = \begin{bmatrix} \text{external characteristics} \\ \text{internal characteristics} \end{bmatrix}$$

Assumes that  $V$  is large enough to contain a statistically significant portion of the population.

- Microscopic Equation of Continuity


$$\frac{\partial f(z, t)}{\partial t} + \nabla \cdot (f(z, t)v_z) = B - D$$

# Application to Crystallization

## Population Balance:

$$\frac{\partial f(L, t)}{\partial t} = -G \frac{\partial f(L, t)}{\partial L}$$

in which  $f(L, t)$  is the number of crystals of size  $L$  at time  $t$ , and  $G$  is the crystal growth rate.



## Mass and Energy Balances:


$$\frac{dC}{dt} = -3\rho_c k_v h G \int_0^\infty f L^2 dL \quad \rho V C_p \frac{dT}{dt} = -3\Delta H_c \rho_c k_v V G \int_0^\infty f L^2 dL - UA(T - T_j(t))$$

## Nucleation and Growth in the Bulk:

$$B = k_b \left( \frac{C - C_{sat}(T)}{C_{sat}(T)} \right)^b = k_b S^b \quad G = k_g \left( \frac{C - C_{sat}(T)}{C_{sat}(T)} \right)^g = k_g S^g$$

# A Stochastic Population Balance Alternative

## Reaction Mechanism for Nucleation and Growth



$N_n$  is the number of crystals of size  $(n + 1)\Delta$  per volume.

### Mass Balance

$$M_{tot} = M_{sat} + M$$

### Energy Balance

$$\frac{dT}{dt} = \frac{UA}{\rho C_p V} (T_j - T)$$


(between reaction events)

## Solubility Relationship

$$M_{sat}(T)$$

# Simulating reactions stochastically

- Stochastic kinetic models treat reactions as **molecular events**
- Consider the well-mixed reaction:



$$\begin{bmatrix} A_o \\ B_o \\ C_o \end{bmatrix} = \begin{bmatrix} 10 \\ 50 \\ 0 \end{bmatrix} \text{ molecules}$$


- Scale probabilities by reaction rates
  - $r_1 = k_1 AB$
  - $r_2 = k_{-1} C$
  - $r_{\text{tot}} = r_1 + r_2$

- Randomly select [4, 5, 18]
  - When the next reaction occurs

$$p(\tau) = r_{\text{tot}} e^{-r_{\text{tot}} \tau}$$


$$\tau = -\frac{\log(p_1)}{r_{\text{tot}}}$$

- Which reaction occurs




# Stochastic Simulation of $A + B \rightleftharpoons C$


One simulation




Average of many simulations




# Implications for Crystal Populations




## Connection to Deterministic Kinetics ( $\Omega = \text{System Size}$ ) for $A + B \rightleftharpoons C$



## Reaction Events for CO oxidation



## Diffusion Events




Repulsive CO-CO interactions increase rate constants


## Surface Reactions: Points of Interest

- Adsorbate diffusion is fast compared to reaction rates,  $\frac{d}{k} \approx O(10^5)$ , stops stochastic simulations
- Fast diffusion does NOT mean random particle placement

Fast diffusion with interactions



Random particle placement





# Order Reduction of the Stochastic Master Equation

## The chemical master equation

$$\frac{dP(x)}{dt} = \sum_{\beta} W_{x,\beta} P(\beta) - W_{\beta,x} P(x)$$

- For a small (100 sites) lattice the size of the state vector  $P$  is  $3^{100} \approx 10^{48}$ .

## Master equation order reduction: fast diffusion limit

- Between reaction events, the lattice samples an equilibrium distribution specified by only species number [6].
- We can show that:


$$\frac{dP(n)}{dt} = \sum_j k_j [\langle s_j(n - \nu_j) \rangle P(n - \nu_j) - \langle s_j(n) \rangle P(n)]$$

- $\langle s_j(n) \rangle$  is the average number of reaction  $j$  that can occur given species number  $n$ , and is calculated by short diffusion only simulations.
- For a small (100 sites) lattice the size of the state vector  $P$  is 5050, solvable linear system.

## Surface Reactions: The $\Omega \rightarrow \infty$ limit


- As the lattice size increases, we switch from a discrete extensive variable  $n$  to a continuous intensive variable  $\theta$  (coverage).
- The reduced master equation can be approximated by an ODE for each species:

$$\frac{d\theta}{dt} = \sum_j k_j \nu_j \langle s_j(\theta) \rangle$$




# Implications for Crystal Populations


## Distributions



⋮




⋮




Stochastic


## Scalars



⋮



⋮




Deterministic

$$\frac{dN_j}{dt} = kM(N_{j-1} - N_j)$$

$\Omega \rightarrow \infty$

$\Delta \rightarrow 0$




$$\frac{\partial \eta(l, t)}{\partial t} = -k'M \frac{\partial \eta(l, t)}{\partial l}$$

# Isothermal, Size-Independent Nucleation and Growth

## Stochastic Solution

Average of 100 Simulations




Discrete particle sizes

Integer-valued particle accounting

## Deterministic Solution

Via Orthogonal Collocation




Continuous particle sizes

Real-valued particle accounting

# Nonisothermal, Size-Independent Nucleation and Growth


## Stochastic Solution

Average of 500 Simulations



## Deterministic Solution


Via Orthogonal Collocation



# Isothermal, Size-Independent Nucleation, Growth, and Agglomeration

## Stochastic Solution



Add one reaction:  $N_p + N_q \xrightarrow{k_a} N_{p+q}$   
Average of 500 Simulations



## Deterministic Solution

Via Adaptive Mesh Methods?  
Large time investment!

## Particle shape




- High value-added products in the chemical industry are becoming increasingly complicated in structure.
- Pharmaceutical compounds are very complex: multiple crystal habits and multiple crystal structures.

## Particle shape—industrial characteristics and challenges


- Particle shape is affected by unmeasured disturbance variables that cannot be modeled nor controlled.
- Online sensing is available in the form of video images. The images are replete with bad data.
  - Particles are fused or broken; particle boundaries overlap.
  - It is difficult to obtain representative samples.
  - It is difficult to sample enough images to remove the effects of noise through averaging.
- Standard image analysis software provides simple shape measures such as particle boxed area and aspect ratio. These simple measures are inadequate signals for feedback control.

## Macroscopic sodium chlorate ( $\text{NaClO}_3$ ) habit




- The 110, 111 and  $\bar{1}\bar{1}\bar{1}$  faces grow fast under relatively high supersaturation and “grow out” leaving only the 100 faces visible under microscopy.

## Macroscopic sodium chlorate ( $\text{NaClO}_3$ ) habit



- In the presence of sodium dithionite ( $\text{Na}_2\text{S}_2\text{O}_6$ ) the  $\bar{1}\bar{1}\bar{1}$  faces are blocked by the impurity and the 100, 110 and 111 faces grow relatively faster, leaving only the  $\bar{1}\bar{1}\bar{1}$  faces visible, seen as a tetrahedron under microscopy.
- See Sherwood, Ristic, and coworkers for further discussion [16, 15]


# Experimental apparatus



- Cascaded MPC-PI temperature controller.
- Automated image analysis system provides on-line information about particle size and shape by binarizing images of samples of the crystal slurry.


# Sodium chlorate shape manipulation

Figure i 15 min  
no habit modifier




200 μm

Figure ii 49 min  
225ppm Na<sub>2</sub>S<sub>2</sub>O<sub>6</sub>




200 μm

Figure iii 70 min  
225ppm Na<sub>2</sub>S<sub>2</sub>O<sub>6</sub>



200 μm

Figure iv 135 min  
no habit modifier




200 μm

# Perturbations to squares and equilateral triangles

		square	triangle
aspect ratio	$\frac{L_{\max}}{L_{\min}}$	$\sqrt{2}$	$\frac{3\sqrt{3}}{4}$
roundness	$\frac{per^2}{4\pi area}$	$\frac{4}{\pi}$	$\frac{9}{\pi\sqrt{3}}$
boxed area	$\frac{object\ area}{bounding\ box\ area}$	1.0	0.5


- Saw tooth waves of increasing amplitude are added to the boundaries of a square and triangle and sized to assess the reliability of the sensor.




# Classification of shape

- The size of the elliptical regions is chosen to classify the shapes.
- Only data within the elliptical regions are used.

Classification regions




Classification regions and data




# Processed image data

- Sensor detects clearly shape change using square and triangle regions alone.



# Feedback control of particle shape to steady state




- By maintaining the habit modifier at a level near the critical impurity concentration, simple PI control algorithms are able to keep a desired habit in the presence of a disturbance. The controller finds the critical dosage (140-160 ppm) required to achieve 40% cubes in a slurry without any knowledge of a model. This value agrees with literature values of 50-210 ppm (Sherwood 1993).



## Limitations of current vision-based measurements

- Commercial, vision-based particle characterization instruments require sampling.
- Literature methods are inadequate for typical industrial, in situ images<sup>1</sup>



<sup>1</sup>Calderon De Anda et. al., *Chemical Engineering Science*, 2005.

## Model-based object recognition for shape measurement

### Advantages


- 1 Parallel, distributed algorithms.
- 2 Robust to noise or missing data.
- 3 Generalizable to many shapes.

### Basic approach<sup>2</sup>


- 1 Find linear features in the image.
- 2 Find linear feature clusters that appear significant on the basis of viewpoint-independent relationships (collinearity, parallelism, and end-point proximity).
- 3 Fit a two or three-dimensional model to each line cluster.

<sup>2</sup>Lowe, D.G., *Artificial Intelligence*, 1987.


## 2-D model-based image analysis for needles




Original image




Linear feature detection



Collinearity identification




Parallelism identification



Cluster properties


## Results for pharmaceutical crystallization

Time = 85 min. after seeding, Temp. = 44 deg. C




## Results for pharmaceutical crystallization

Time = 85 min. after seeding, Temp. = 44 deg. C




## Results for pharmaceutical crystallization

Time = 265 min. after seeding, Temp. = 20 deg. C



# Results for pharmaceutical crystallization


Time = 265 min. after seeding, Temp. = 20 deg. C




## Comparison of automatic and manual measurement

Time (min.)	Temp. (deg C)	Mean Size, ( $\mu\text{m}$ )		Percent Difference
		Manual	Automatic	
85	44	284	300	5.5
125	41	291	292	0.4
210	30	288	286	0.7
265	20	356	303	14.8


85 min., 44 deg C



210 min., 30 deg C





265 min., 20 deg C




## 3-D models for more complex shapes


- Parameterized, wireframe model.
- Viewpoint-invariant groups used as cues for location and size of crystals in image.




Junction



Parallel pair



Symmetric pair







Arrow


## Application to in situ image

### Algorithm steps:


- Identify linear features in image.
- Identify significant, viewpoint-invariant groups.
- Use the location, orientation, and lengths of the lines in the group to estimate the crystal's size and orientation.




## Example 1: $\alpha$ -glycine crystal




(a) Original image




(b) Linear features




(c) Salient line group



(d) Model initialization




(e) Further matches




(f) Optimized Fit


## Example 2: $\gamma$ -glycine crystal




(a) Original image




(b) Linear features




(c) Salient line group



(d) Model initialization




(e) Further matches




(f) Optimized Fit


## Application to full image: $\alpha$ -glycine




## Application to full image: $\alpha$ -glycine



## Application to full image: $\gamma$ -glycine



## Application to full image: $\gamma$ -glycine





## Conclusions

- If you want to understand data . . . you have to model them
- Good models enable good engineering: design, monitor, forecast, control
- Crystal engineering poses challenging modeling problems, but progress is steady and breakthroughs are possible
  - off-the-shelf data/model combinations are *often* incompatible
  - these applications require state-of-the-art modeling tools for numerical solution, parameter estimation, optimization and control
- We are capable of modeling, monitoring and controlling many systems with current technology

## Measurement Technology

- Model-based vision is a promising method for automating the measurement of crystal size and shape distributions in noisy, in situ images.
- Both needle and template-based algorithms have been developed and applied for specific shapes. The needle algorithm achieves results roughly as good as those obtained from manual sizing of crystals. Further validation is needed for the template algorithm.
- The algorithms are fast and likely suitable for real-time measurement of crystal size and shape distributions and polymorphic composition.

- More and better sensors
  - in-situ video imaging for on-line particle analysis appears feasible
  - commercial instrument vendors are very active
  - complex product specifications require better sensors
- More and better models
  - couple ab initio molecular, chemical models to process models
  - move from simple scaling heuristics to mixing models based on computational fluid dynamics
  - real-time compression of large sets of video data into useful information
  - stochastic simulation of complex population behavior

## Acknowledgments

### Ph.D. Students and Postdocs

- Paul A. Larsen and Ethan A. Mastny
- Eric L. Haseltine (graduated 2/2005)
- Daniel B. Patience (graduated 8/2002)

### Funding

- GlaxoSmithKline
- Mitsubishi Chemical
- International Fine Particle Research Institute (IFPRI)
- Amoco
- National Science Foundation

## Further Reading I

- [1] T. Allen. *Particle Size Measurement*. Chapman and Hall, London, fifth edition, 1997.
- [2] M. H. Bharati and J. F. MacGregor. Multivariate image analysis for real-time process monitoring and control. *Ind. Eng. Chem. Res.*, 37:4715–4724, 1998.
- [3] R. D. Braatz and S. Hasebe. Particle size and shape control in crystallization processes. In *Chemical Process Control—CPC 6*, pages 307–327, Tucson, Arizona, January 2001.
- [4] D. T. Gillespie. A general method for numerically simulating the stochastic time evolution of coupled chemical reactions. *J. Comput. Phys.*, 22:403–434, 1976.
- [5] D. T. Gillespie. Exact stochastic simulation of coupled chemical reactions. *J. Phys. Chem.*, 81:2340–2361, 1977.
- [6] E. L. Haseltine and J. B. Rawlings. On the origins of approximations for stochastic chemical kinetics. *J. Chem. Phys.*, 123:164115, October 2005.
- [7] C. M. G. Heffels, D. Heitzmann, E. D. Hirleman, and B. Scarlett. The use of azimuthal intensity variations in diffraction patterns for particle shape characterization. *Part. Part. Syst. Charact.*, 11:194–199, 1994.

## Further Reading II

- [8] C. M. G. Heffels, D. Heitzmann, E. D. Hirleman, and B. Scarlett. Forward light scattering for arbitrary sharp-edged convex crystals in Fraunhofer and anomalous diffraction approximations. *Applied Opt.*, 34(26):6552–6560, 1995.
- [9] H. B. Matthews and J. B. Rawlings. Batch crystallization of a photochemical: Modeling, control and filtration. *AIChE J.*, 44:1119–1127, 1998.
- [10] O. Monnier, G. Fevotte, C. Hoff, and J. P. Klein. Model identification of batch cooling crystallizations through calorimetry and image analysis. *Chem. Eng. Sci.*, 52(7):1125–1139, 1997.
- [11] D. B. Patience, H. A. Mohameed, and J. B. Rawlings. Crystallization of para-xylene in scraped-surface crystallizers. *AIChE J.*, 47(11):2441–2451, 2001.
- [12] D. B. Patience and J. B. Rawlings. Particle-shape monitoring and control in crystallization processes. *AIChE J.*, 47(9):2125–2130, 2001.
- [13] C. J. G. Plummer and H. H. Kausch. Real-time image analysis and numerical simulation of isothermal spherulite nucleation and growth in polyoxymethylene. *Colloid Polym. Sci.*, 273:719–732, 1995.
- [14] J. B. Rawlings, S. M. Miller, and W. R. Witkowski. Model identification and control of solution crystallization processes: A review. *Ind. Eng. Chem. Res.*, 32(7):1275–1296, July 1993.

- [15] R. Ristić, B. Y. Shekunov, and J. N. Sherwood. Growth of the tetrahedral faces of sodium chlorate crystals in the presence of dithionate impurity. *J. Cryst. Growth*, 139(3-4):336–343, 1994.
- [16] R. Ristić, J. N. Sherwood, and K. Wojciechowski. Morphology and growth kinetics of large sodium chlorate crystals grown in the presence and absence of sodium dithionate impurity. *J. Phys. Chem.*, 97(41):10774–10782, 1993.
- [17] R. D. Rovang and A. D. Randolph. On-line particle size analysis in the fines loop of a KCl crystallizer. *AIChE Symp. Ser.*, 76(193):798–807, 1980.
- [18] B. H. Shah, D. Ramkrishna, and J. D. Borwanker. Simulation of particulate systems using the concept of the interval of quiescence. *AIChE J.*, 23(6):897–904, 1977.
- [19] H. C. van de Hulst. *Light Scattering by Small Particles*. Dover Publications, New York, 1981.